
Installation Manual of Single end or Double end (Ballast Compatible) LED tubes

Single end LED tube



* Ballast must be removed from existing fitting.

Important!

If your fittings have starters, make sure to remove them before inserting the new tube.

